

Wash Wax Mop

Directions

Contents: 1 Extension Pole, 1 Mop head, 2 Mop Pads.

1. Screw the extension pole into the Mop head
2. Place the microfiber pads on both sides of the Mop.
3. Spray the *Wet side* with 8-18 spray pumps of Wash Wax ALL. (This is to prime a new dry pad. Once the pad has been primed, it will typically only take 3-4 spray pumps to prepare for the next area.)
4. Apply the Wash Wax ALL to the area to be cleaned (approx. 4ft. x 4ft. area) with the wet side of the mop, using a back and forth motion. (If the area is very dirty you may also want to spray Wash Wax ALL directly onto the surface.)
5. Flip the Mop over to the dry side and dry the area. For best results, dry the Wash Wax ALL before it dries.
6. For the next area, you only need 3-4 spray pumps of Wash Wax ALL. You can either spray the surface to be cleaned directly, or spray the wet side of the Mop again. If you are spraying the surface from a distance, you may want to switch the spray nozzle to the stream setting.
7. Once the wet side pad gets dirty, replace it with the dry side pad and put a fresh clean pad on the dry side. This will allow you to get the most use out of your pads.

Helpful Hints:

Do Not use the Mop from a ladder

Do not use for Wet Washing

The wet side should only be damp. Do not over-saturate the wet side or you may begin to see streaking. Replace the pads regularly.

Top Down, do the high areas first to prevent spray mist from landing on clean areas.

Stay Up wind, keep the dirty areas downwind of your cleaning spray.

Do the dirtiest painted areas last. Then put two (2) fresh and clean Mop Pads on and clean the windows.

Keep in mind when it's hot and dry the surface will dry faster, so you will do smaller areas at a time. When it is cold and damp it takes longer to dry so you will do larger areas.

Avoid placing the Mop on the ground. The pads may pick up contaminants that can scratch the surface.

Machine wash the microfiber pads with laundry detergent and machine dry. Do not use fabric softener, as this will make the microfiber water resistant. To avoid lint, do not wash microfiber with cotton products.

Do not wash mop pads or towels with shop towels that may contain metal shavings of sharp contaminants. Avoid laundry services that wash towels for machine shops.

Inspect mop pads and towels for contamination that may scratch after washing and before each use.

Tighten the wing nuts to prevent the Mop from pivoting too easily. We recommend that the wing nuts be tight enough to provide some resistance when you pivot or swivel the mop by hand.

We do not recommend using the Mop with an extension pole longer than 12 feet.

There is a locking pin for the swivel. We recommend that you leave it locked when you first start using the Mop. Once you are comfortable using the Mop, take out the pin and store it in the hole below the lock hole. At first it may seem difficult to control, but once you get the feel of it, you may want to leave it unlocked. The unlocked position gives you greater flexibility and maneuverability using the mop. Whether you leave the lock in or take it out is your personal preference.

For more information visit www.washwax.com or call 1-800-WashWax.